



PICTURE SHOWS COMPONENTS FROM THE INSIDE OF CHASSIS.

REMARK:
FORM A SLOPE SO THAT PE-CONNECTION WILL BECOME THE LAST TO STRIP OFF IN CASE OF PULLING FORCE TO MAINS CABLE:

SOME RECOMMENDATIONS:

KEEP POWER WIRES AWAY FROM SIGNAL LINES. DRILL AC WIRES FIRMLY AND GIVE THEM SEPARATE WAY. PUT FILAMENT'S POWER WIRES WELL DRILLED ALONG THE INNER CHASSIS BEND AWAY FROM THE REST.

SIGNAL WIRES FROM INPUT SOCKETS TO V1 AND FROM V1 TO VOLUME POT SHOULD BE SHIELDED.

ALWAYS KEEP WIRES AS SHORT AS POSSIBLE.

Princeton Reverb Amp Clone (AA1146)				
Sheet		Physical Layout		
Code	Document	Rev.		
BB2008	princeton_reverb_docs_new.spl7	A5		
Date	Last edit	Sheet		
25.10.2013	10:04:49	3 of 3		